

FIG. 1




FIG. 2




FIG. 3




FIG. 14




FIG. 4




FIG. 9




FIG. 5




FIG. 6




FIG. 13

FIG. 7

FIG. 8  
RECEIVE INCOMING CALL OR MESSAGE SIGNAL  
VIA BI-DIRECTIONAL COMMUNICATION (TELEPHONE) CHANNEL

S11

SWITCH BROADCAST (RADIO) RECEIVER MODULE ON

S12

TUNE TO A PREDETERMINED BROADCAST CHANNEL

S13

CHECK WHETHER THERE IS  
PROGRAM ON THE TUNED (RADIO)  
BROADCAST CHANNEL

S14

PROGRAM ON

PLAY RECEIVED (RADIO) PROGRAM TO INDICATE  
AN INCOMING (TELEPHONE) CALL OR MESSAGE

S16

TUNE TO ANOTHER  
BROADCAST CHANNEL

S15

SWITCH BROADCAST RECEIVER (RADIO) MODULE OFF UPON USER RESPONSE  
TO SAID INDICATION OF INCOMING (TELEPHONE) CALL OR MESSAGE

S17




FIG. 10




FIG. 11




FIG. 12